



## OPTISENS MAC 100 Technical Datasheet

Multiparameter signal converter

- Unified converter platform for analysis, flow and level
- Unified user interface
- Unified service philosophy

The documentation is only complete when used in combination with the relevant documentation for the sensor.

1 Product features	4
1.1 Multiparameter converter for liquid analytical measurements	4
1.2 Modular structure	6
1.3 Sensor input combinations	7
1.4 Measuring principle	7
2 Technical data	8
2.1 Technical data table	8
2.2 Dimensions and weight	12
2.2.1 Housing	12
2.2.2 Mounting plate	13
3 Installation	14
3.1 Notes on installation	14
3.2 Intended use	14
3.3 Storage and transport	14
3.4 Wall mounting	15
4 Electrical connections	17
4.1 Safety instructions	17
4.2 Used abbreviations	17
4.3 Important device-specific notes on electrical connection	18
4.4 Opening the converter housing	19
4.5 Overview of the terminal compartment	19
4.6 Connecting the signal cables	20
4.7 Connecting the power supply	20
4.8 Description and properties of the outputs and the input	22
4.8.1 Current output	22
4.8.2 Relay outputs	22
4.8.3 Control input (passive)	23
4.9 Connection diagrams of the outputs and the input	24
4.9.1 Important notes	24
4.9.2 Description of electrical symbols	24
4.9.3 Block diagram	25
4.9.4 Current output (active)	25
4.9.5 Relay outputs	26
4.9.6 Control input	26
4.10 Electrical connection of the outputs and the input	27
4.10.1 Connecting the current outputs	27
4.10.2 Connecting the relay outputs	28

---

5 Order information	31
5.1 Order code .....	31
6 Notes	33

---

## 1.1 Multiparameter converter for liquid analytical measurements

The OPTISENS MAC 100 has a standardised operating concept, which is praxis proven since years in flow and level converters. With this KROHNE is the first manufacturer to have a unified device concept to measure physical parameters as well as analytical parameters. The benefit for you is that quick commissioning, reduced training times and standardisation of your hardware simplify the operating process and further reduce your costs.



- ① Display
- ② Operation keys
- ③ Cable feedthroughs

### Highlights

- KROHNE General Device Concept (GDC)
- Standardised operating concept from flow and level extended to analytical parameters
- Up to 2 sensor inputs + temperature input
- 3 current outputs
- Large graphic display
- Robust aluminium housing (IP66)
- Build-in temperature and pH compensation
- Calibration logbook
- HART (in preparation)

### Industries

- Water / Waste water
- Power industry
- Process industry
- Food and Beverages

## 1.2 Modular structure



### For tailored solutions

The "modular structure" means that the device can be adapted perfectly for your requirements: you specify the number and type of signal inputs and outputs, you define the complexity of the measuring point and the number of parameters. The standardised user interface also speeds up commissioning of the device and opens access to a wide range of diagnostic functions for devices and processes.



(OPTISENS AAS 1000 sensor)

### Sensor series

You can connect both the analogue sensors of the OPTISENS 1000 series and the digital sensors of the OPTISENS 2000 series. This means one single converter can handle the wide variety of applications in the water and wastewater industry.

## 1.3 Sensor input combinations

You can order the converter as single or dual channel instrument. The following combinations of sensor inputs are possible:

Sensor type	Measured parameter	Measuring principle	Signal converter	
			Input A	Input B
PAS 1000 pH	pH value	Potentiometric	X	X
PAS 1000 ORP	ORP value	Potentiometric	X	X
AAS 1000 Cl <sub>2</sub>	Free chlorine	Amperometric	X	-
AAS 1000 ClO <sub>2</sub> ①	Chlorine dioxide	Amperometric	X	-
AAS 1000 H <sub>2</sub> O <sub>2</sub> ①	Hydrogen peroxide	Amperometric	X	-
AAS 1000 O <sub>3</sub> ①	Ozone	Amperometric	X	-
AAS 1000 DO ①	Dissolved oxygen	Amperometric	X	X
CAS 1000 ①	Conductivity / specific resistance	Conductive (2-pole)	X	X
IAS 1000 ①	Conductivity	Inductive	X	X

① In preparation

## 1.4 Measuring principle

The measuring principle depends on the used sensor(s), for further information refer to the sensor manual(s).

## 2.1 Technical data table

- *The following data is provided for general applications. If you require data that is more relevant to your specific application, please contact us or your local representative.*
- *Additional information (certificates, special tools, software,...) and complete product documentation can be downloaded free of charge from the website (Download Center).*

*The following data are relevant only for the non-Ex version. For technical data of the Ex-version refer to the Ex-manual.*

### Measuring system

Measuring principle	Depends on the used sensor(s), for further information refer to the sensor manual(s).
Application range	Continuous measurement of parameters in liquid analysis applications.
Measuring range	Depends on the used sensor(s), for further information refer to the sensor manual(s).

### Design

Construction	A typical measuring system consists of: <ul style="list-style-type: none"><li>• MAC 100 multiparameter signal converter</li><li>• 1 (or up to 2) sensors of the OPTISENS series</li><li>• Sensor cable</li><li>• MAA mounting assemblies</li></ul>
Option	The device is available as a one channel (one signal input) or a two channel version (two signal inputs). You can connect one sensor to the one channel version and up to two sensors to the two channel version.
Sensors	For further information refer to the manual of the relevant sensor. Also note the table with the sensor input combinations on page 7.

Display and user interface	
Graphic display	LC display, backlit white
	128 x 64 pixels
	Note: ambient temperatures below -25°C / -13°F" may affect the readability of the display!
Operating elements	4 push buttons for operator control of the signal converter without opening the housing.
Operating menu	The operation menu consists of the measuring mode and the menu mode:
	Measuring mode: 4 pages (first and second measuring page with measuring results, status message and trend diagram).
	Menu mode: variety of main and submenus that allow to customise the device according to the demands of the measuring point.
Operating and display languages	English, German, (others on request)
Units	Metric, British and US units selectable as required from lists.

### Measuring accuracy

Reference conditions	Temperature: 20°C / 68°F Pressure: 1 bar / 14.5 psi
Maximum measuring error	For further information refer to the manual of the relevant sensor.
Repeatability	For further information refer to the manual of the relevant sensor.
Resolution	Temperature: 0.1°C / 0.1°F"
	For further information refer to the manual of the relevant sensor.
Long-term stability	24 hours: tested within accuracy definition
Temperature drift	Tested within accuracy definition
Cable length variation	Tested within accuracy definition

### Operating conditions

Temperature	
Ambient	-15...+55°C / +5...131°F
	Note: the manufacturer strongly recommends to protect the signal converter from external heat sources such as direct sunlight as higher temperatures reduce the life cycle of all electronic components!
Storage	-40...+70°C / -40...+158°F

<b>Other conditions</b>	
Humidity (ambient)	Max. 90% at 40°C / 104°F
Pressure	For information about the process pressure of the used sensor(s) refer to the relevant sensor documentation!
Protection category acc. to IEC 529 / EN 60529:	IP66/67 (acc. to NEMA 4/4X)

### Installation conditions

Installation	Only wall mounting is possible, always assure a vertical mounting orientation!
Dimensions and weights	For detailed information see chapter "Dimensions and weights".

### Materials

Signal converter housing	Die-cast aluminium (polyurethane coated)
Measuring sensor	For housing materials, process connections, liners, grounding electrodes and gaskets, see the technical documentation for the measuring sensor.

### Electrical connections

General	Electrical connection is carried out in conformity with the VDE 0100 directive "Regulations for electrical power installations with line voltages up to 1000 V" or equivalent national regulations.
<b>Power supply</b>	
Voltage	100...230 VAC (-15% / +10%), 50/60 Hz; 240 VAC + 5% is included in the tolerance range. 12...24 VAC/DC (in preparation)
Power consumption	4.2 W, 10 VA at 230 VAC
Fuse	0.8 AT/250V (high breaking capacity), 5 x 20 mm / 0.2 x 0.8"
Line frequencies	50/60 Hz
Power rating	22 VA (maximum)
Inrush current	$I_{N,eff} = 97 \text{ mA}$ , $t_{15} = 1.5 \text{ ms}$ , $t_{Peak} = 200 \mu\text{s}$ , $I_{Peak} = 22.6 \text{ A}$
Cable entries	1 channel: 4 x M20 2 channels (separate temperature sensor): 3 x M20, double PG two times 5 mm / 0.20" screwed connection for sensor cables 2 channels (integrated temperature sensor): 3 x M20, double PG two times 8 mm / 0.31" screwed connection for sensor cables

## Inputs and outputs


General	All in- and outputs are electrically isolated from each other and from all other circuits.
	All operating data and output values can be adjusted.
Description of used abbreviations	$U_{ext}$ = external voltage; $R_L$ = load + resistance; $U_0$ = terminal voltage; $I_{nom}$ = nominal current
<b>Inputs</b>	
Sensor inputs	Up to 2, depending on the version. For further information refer to the manual of the relevant sensor.
Control input	Passive, not polarity sensitive, $U_{ext, max} \leq 32$ VDC, $I_{nom} = 6.5$ mA with $U_{ext} = 24$ VDC, $I_{nom} = 8.2$ mA with $U_{ext} = 32$ VDC  Switching point for identifying "contact open or closed": contact open ("off") at $U_0 \leq 2.5$ V with $I_{nom} = 0.4$ mA, contact closed ("on") at $U_0 \geq 8$ V with $I_{nom} = 2.8$ mA
<b>Outputs</b>	
Current outputs	Three isolated outputs (4...20 mA), all galvanic isolated, errors signals 3.25 mA and 22 mA, active mode  Output data: depending on sensor  Operating data: $U_{int, nom} = 15$ VDC, $I = 0(4)...22$ mA, $I_{max} \leq 22$ mA, $R_L \leq 550 \Omega$
Relay outputs	Three electro-mechanical relays that can work as alarm relays or limit switches  Possible conditions: NO (normally open) or NC (normally closed)  Contact ratings: <ul style="list-style-type: none"><li>• Relays for low voltages: <math>U \leq 30</math> VDC, <math>I \leq 1</math> A, resistive load (PELV / SELV) or <math>U \leq 50</math> VAC, <math>I \leq 4</math> A, resistive load (PELV / SELV)</li><li>• Relays for high voltages: <math>U = 100...230</math> VAC, <math>I \leq 4</math> A, max. 1000 VA resistive load</li></ul>
HART	In preparation

## Approvals and certifications

CE	This device fulfils the statutory requirements of the EC directives. The manufacturer certifies successful testing of the product by applying the CE mark.
Shock resistance	IEC 68-2-3
Electromagnetic compatibility	2004/108/EC in conjunction with EN 61326-1 (A1, A2)
Low Voltage Directive	Safety requirements for electrical equipment for measurement, control, and laboratory use in accordance with EN 61010-1:2001.

## 2.2 Dimensions and weight

### 2.2.1 Housing




Dimensions and weights in mm and kg

	Dimensions [mm]										Weight [kg]
	a	b	c	d	e	f	g	h	i	k	
Wall-mounted version	161	40	87.2	120	155	241	95.2	257	19.3	39.7	Std. 1.9

Dimensions and weights in inches and lb

	Dimensions [inch]										Weight [lb]
	a	b	c	d	e	f	g	h	i	k	
Wall-mounted version	6.34	1.57	3.43	4.72	6.10	9.50	3.75	10.12	0.76	1.56	Std. 4.2

### 2.2.2 Mounting plate



Dimensions in mm and inch

	[mm]	[inch]
a	Ø6.5	Ø0.26
b	87.2	3.4
c	241	9.5

### 3.1 Notes on installation

*Inspect the cartons carefully for damage or signs of rough handling. Report damage to the carrier and to the local office of the manufacturer.*

*Check the packing list to check if you received completely all that you ordered.*

*Look at the device nameplate to ensure that the device is delivered according to your order. Check for the correct supply voltage printed on the nameplate.*

### 3.2 Intended use

*Never install or operate the device in potentially explosive areas, it might cause an explosion that can result in fatal injuries.*

*If the device is not used according to the operating conditions (refer to chapter "Technical data"), the intended protection could be affected.*

In combination with the different sensors of the OPTISENS 1000 series the MAC 100 measures analytical parameters in water and waste water applications.

### 3.3 Storage and transport

- Store and transport the device in a dry, dust-free location.
- Avoid continuous direct sunlight.
- Store and transport the device in its original packing.
- Storage temperature: -40...+70°C / -40...+158°F

### 3.4 Wall mounting

*Never install or operate the device in potentially explosive areas, it might cause an explosion that can result in fatal injuries.*

*Always note the following items to ensure a proper and safe installation:*


- *Make sure that there is adequate space to the sides.*
- *Protect the signal converter from direct sunlight and install a sun shade if necessary.*
- *Signal converters installed in control cabinets require adequate cooling, e.g. by fan or heat exchanger.*
- *Do not expose the signal converter to intense vibration.*
- *Use assembly materials and tools in compliance with the applicable occupational health and safety directives (assembly materials and tools are not part of the scope of delivery).*

*Installation, assembly, start-up and maintenance may only be performed by appropriately trained personnel. The regional occupational health and safety directives must always be observed.*

*Assembly materials and tools are not part of the delivery. Use the assembly materials and tools in compliance with the applicable occupational health and safety directives.*


The mounting plate is fixed at the back side of the device in the delivery condition. The following drawings illustrate the proper mounting:

**Wall mounting with plugs**



- Note the drawing above and mark all drill holes with the help of a pen, e.g. a felt pen (1).
- Fasten the device securely to the wall with the help of plugs, screws and the mounting plate (2).

## Wall mounting of multiple devices



	[mm]	["]
a	Ø6.5	Ø0.26
b	87.2	3.4
c	241	9.5
d	310	12.2
e	257	10.1

For further information about the dimensions of the mounting plate refer to *Mounting plate* on page 13.

## 4.1 Safety instructions

*All work on the electrical connections may only be carried out with the power disconnected. Take note of the voltage data on the nameplate!*

*Observe the national regulations for electrical installations!*

*For devices used in hazardous areas, additional safety notes apply; please refer to the Ex documentation.*

*Observe without fail the local occupational health and safety regulations. Any work done on the electrical components of the measuring device may only be carried out by properly trained specialists.*

*Look at the device nameplate to ensure that the device is delivered according to your order. Check for the correct supply voltage printed on the nameplate.*

## 4.2 Used abbreviations

Abbreviation	Description
$C_p$	Control input passive
$I_a$	Current output active
$I_{max}$	Maximum current
$I_{nom}$	Nominal current
$R_L$	Load resistance
R plus number (e.g. R1)	Relay contact
P	Power
$U_{ext}$	External voltage source
$U_{ext, max}$	Maximum voltage of the external voltage source
$U_{int, nom}$	Nominal internal voltage

## 4.3 Important device-specific notes on electrical connection

*Never install or operate the device in potentially explosive areas, it might cause an explosion that can result in fatal injuries!*

*The device must be grounded in accordance with regulations in order to protect personnel against electric shocks.*

*When installing and wiring the device, note the safety regulations of the current state of the art. Also note the following items to avoid fatal injuries, destruction or damage of the device or measuring errors:*


- *De-energise the cables of the power supply before you start any installation works.*
- *Always install input and control cables divided from each other and from high voltage current cables.*
- *Assure that all cables of the inputs and current outputs are shielded. Connect the shieldings only to one side, e.g. to the device.*
- *When using relays, note that with inductive loads the interference must be suppressed.*
- *Assure that all electrical connection works are compliant with the VDE 0100 directive "Regulations for electrical power installations with line voltages up to 1000 V" or equivalent national regulations.*
- *Use suitable cable glands for the various electrical cables and suitable connecting cables for the field of application. The outer diameter of the connecting cables has to fit to the cable glands.*
- *The nominal voltage of the connecting cable has to fit to the operating voltage of the device.*

*Assembly materials and tools are not part of the delivery. Use the assembly materials and tools in compliance with the applicable occupational health and safety directives.*

## 4.4 Opening the converter housing


*Clean and grease all threads each time you open the housing. Use only resin-free and acid-free grease. Before closing the cover, ensure that the housing gasket is properly fitted, clean and undamaged.*

All installation works on the electrical connections require to open the converter housing:



- Loose the four screws (①) with a crosstip screwdriver.
- Lift the housing at the top and bottom at the same time (②).
- Slide the housing cover backward (③).
- ⇒ The housing cover is guided and held by the inside hinge; you have access to the terminal compartment now (see ④ in the previous drawing and next section).

## 4.5 Overview of the terminal compartment



- ① Cover of power supply terminal
- ② Cover of relay outputs terminal
- ③ Current output terminal
- ④ Shield terminal
- ⑤ Terminals for sensor input A
- ⑥ Terminals for sensor input B
- ⑦ Possibility to connect a functional earth (only relevant for 24 V version, which is in preparation)
- ⑧ Cable glands

## 4.6 Connecting the signal cables

*The cable glands installed by the manufacturer are designed for a cable diameter of 8 to 13 mm. If you are using cables with a larger diameter, you must replace the manufacturer's cable glands with suitable ones.*

For all information concerning the signal cables of the used sensor(s) and their connection refer to the relevant sensor handbook(s).

## 4.7 Connecting the power supply

*The device must be grounded in accordance with regulations in order to protect personnel against electric shocks.*


*Never install or operate the device in potentially explosive areas, it might cause an explosion that can result in fatal injuries!*

*When connecting the power supply, always note the safety regulations of the current state of the art. To avoid fatal injuries, destruction or damage of the device or measuring errors, also note the following items:*

- *De-energise the cables of the power supply before you start any installation works!*
- *Always keep the housing of the device well closed if you do not perform any installation works. The function of the housing is to protect the electronic equipment from dust and moisture.*
- *Assure that there is a fuse protection for the infeed power circuit ( $I_{l,nom} \leq 16 \text{ A}$ ) and a disconnecting device (switch, circuit breaker) to isolate the signal converter.*
- *Check the nameplate and assure that the power supply meets the voltage and frequency of the device. You can operate the device in the range of 100...230 VAC and 8 VA with a tolerance of -15/+10% while 240 VAC +5% is included in the tolerance range (a version with a power supply of 24 VAC/DC is in preparation). A power supply outside these specifications may destroy the device!*
- *Assure that the protective earth conductor (PE) is longer than the L- and N-conductor.*

*The manufacturer has designed all creepage distances and clearances according to VDE 0110 and IEC 664 for pollution degree 2. The power supply circuits fulfil the overvoltage category III and the output circuits fulfil the overvoltage category II.*


Before you start to connect the power supply cables, note the following drawing with the function of the terminals:



- ① L1...L3 (live)
- ② Neutral
- ③ Protective Earth (PE)

Afterwards connect the power supply cables accordingly:

*The manufacturer strongly recommends to use a slotted screwdriver with a tip of 3.5 x 0.5 mm / 0.14 x 0.02" to push down the lever! Otherwise you could damage the lever.*



- De-energise the power supply cables with the help of a disconnecting device (switch, circuit breaker)!
- Open the converter housing ( refer to *Opening the converter housing* on page 19).
- Remove the cover of the power supply terminal (①) by pressing it down and pulling forwards at the same time (② and ③), be careful and do not disrupt the retaining band (it prevents the cover from getting lost)!
- Use a slotted screwdriver with a tip of 3.5 x 0.5 mm / 0.14 x 0.02" to push down the lever, connect the wires to the terminals and pull up the levers again (④ and ⑤).
- Refasten the cover of the power supply terminal, close the converter housing and tighten all screws of the housing.

## 4.8 Description and properties of the outputs and the input

### 4.8.1 Current output

*Never install or operate the device in potentially explosive areas, it might cause an explosion that can result in fatal injuries.*

*For further information refer to the connection diagrams and the technical data table.*

- All outputs are electrically isolated from each other and from all other circuits.
- All operating data and functions can be adjusted.
- Output data: measuring results of the sensor inputs A and B inclusive temperature.
- Active mode: output range 0(4)...20 mA, load resistance  $R_L \leq 550 \Omega$  at  $I_{max} \leq 22$  mA,  $U_{int, nom} = 15$  VDC.
- Self-monitoring: interruption or load resistance too high in the current output loop.
- Error signalling possible via alarm relays, error indication on LC display.
- Current value error detection can be adjusted.

### 4.8.2 Relay outputs

*Never install or operate the device in potentially explosive areas, it might cause an explosion that can result in fatal injuries.*

*For further information refer to the diagrams on page 25 and on page 26 as well as the technical data table on page 8.*

The device has three electro-mechanical relays that can work as alarm relays or limit switches (electronic relays are in preparation):

- The relay contacts are electrically isolated from each other and from all other circuits.
- The output stages of the status outputs / limit switches behave like relay contacts.
- Possible conditions: NO (normally open) or NC (normally closed).
- Contact ratings:
  - Relays for low voltages:  $U \leq 30$  VDC,  $I \leq 1$  A, resistive load (PELV / SELV) or  $U \leq 50$  VAC,  $I \leq 4$  A, resistive load (PELV / SELV)
  - Relays for high voltages:  $U = 100...230$  VAC,  $I \leq 4$  A, max. 1000 VA resistive load
- The contact circuits have to be either PELV / SELV circuits or hazardous voltage circuits.

### 4.8.3 Control input (passive)

*Pay attention to the maximum voltage and current values which can be applied to the control input! Applying power outside the allowed range can destroy or damage the device!*

*The factory default is a disabled control input!*

The passive control input can trigger different events in the converter from outside. It is engaged via applying a voltage of  $U_{on} > 8$  VDC and disengaged via applying a voltage of  $U_{off} < 2.5$  VDC. The properties in detail are the following:

- Passive, not polarity sensitive
- Condition "off":  $U_{off} \leq 2.5$  VDC with  $I_{nom} = 0.4$  mA
- Condition "on":  $U_{on} \geq 8$  VDC with  $I_{nom} = 2.8$  mA
- $U_{ext, max} \leq 32$  VDC
- $I_{nom} = 6.5$  mA with  $U_{ext} = 24$  VDC
- $I_{nom} = 8.2$  mA with  $U_{ext} = 32$  VDC

For instance the control input can work together with a flow monitor that monitors the sample flow and gives a signal if the flow drops below a certain threshold. If in this case the control input has the setting "flow control", it triggers an "out of specification error" (this error indicates that the measured value cannot be trusted anymore). For more information refer to the table of the error category "Out of specification" in the manual..

There are other purposes for the usage of the control input. For detailed information refer to the function C3.5 and especially C3.5.1 in the corresponding function table of the manual..




## 4.9 Connection diagrams of the outputs and the input

### 4.9.1 Important notes


*Never install or operate the device in potentially explosive areas, it might cause an explosion that can result in fatal injuries.*

- All groups are electrically isolated from each other and from all other input and output circuits.
- Depending on the version, the inputs/outputs must be connected passively or actively or acc. to NAMUR EN 60947-5-6 (refer to the sticker in the cover of the terminal compartment for information about the I/O version and inputs/outputs of your device).
- Passive operating mode: an external power supply is necessary to operate (activation) the subsequent devices ( $U_{ext}$ ).
- Active operating mode: the signal converter supplies the power for operation (activation) of the subsequent devices, observe max. operating data.
- Terminals that are not used must not have any conductive connection to other electrically conductive parts.

### 4.9.2 Description of electrical symbols

Symbol	Description
	mA meter, 0...20 mA or 4...20 mA and other, $R_L$ is the internal resistance of the measuring point including the cable resistance
	DC voltage source ( $U_{ext}$ ), external power supply, any connection polarity
	DC voltage source ( $U_{ext}$ ), observe connection polarity according to connection diagrams
	Internal DC voltage source
	Controlled internal power source in the device
	Button, NO contact or similar

### 4.9.3 Block diagram




- ① Power supply (100...230 VAC)
- ② Control input (non-polarised), 8...32 VDC
- ③ Sensor input B, refer to sensor handbook (the terminals P, U and X show an example with a NTC resistor)
- ④ Sensor input A, refer to sensor handbook (the terminals P, U and X show an example with a Pt100/1000 resistor)
- ⑤ Current outputs A and B
- ⑥ Current output C, HART (in preparation)
- ⑦ Relay outputs R1, R2 and R3

### 4.9.4 Current output (active)

*To avoid damage or destruction of the device always note the following items:*

- *Observe the connection polarity!*
- *Note the properties of the current output, further information on page 25.*


Connection diagram of current output (active)



#### 4.9.5 Relay outputs

*To avoid damage or destruction of the device always note the properties of the relay outputs, further information on page 22.*


##### Example: different conditions of a relay output



- ① Normal operation: device in operation and no current error message, indicator lamp off, relay contact open.
- ② Alarm condition: error message occurs, indicator lamp on, device de-energised or with malfunction, relay contact closed.

#### 4.9.6 Control input

*To avoid damage or destruction of the device always note the properties of the control input, further information on page 23.*



- ① Signal

## 4.10 Electrical connection of the outputs and the input

*All work on the electrical connections may only be carried out with the power disconnected. Take note of the voltage data on the nameplate!*


*Assembly materials and tools are not part of the delivery. Use the assembly materials and tools in compliance with the applicable occupational health and safety directives.*

- Open the housing cover (refer to *Opening the converter housing* on page 19).
- Push the prepared cables through the cable entries and connect the necessary conductors.
- Connect the shield.
- Tighten the screw connection of the cable entry securely.
- Seal all cable entries that are not needed with a plug.
- Close the housing cover.

*Ensure that the housing gasket is properly fitted, clean and undamaged.*

### 4.10.1 Connecting the current outputs

*Use the correct cable gland, refer to the following drawing and to the section "device description" in the manual.*



- Conduct the cables with prefabricated shielding through the correct cable glands (① and ②).
- Insert the cable into the terminal (③).
- To remove the cable push the lever down with a suitable tool (④) and pull the cable out of the terminal (⑤).

#### 4.10.2 Connecting the relay outputs

*To avoid dangerous voltages, the switching voltage for the relay contacts must fulfill one of the following conditions: it must either originate from the same network as the signal converter power supply including pre-fuse and separator (see Section 4.6) or come from a SELV or PELV network. When installing, always comply with the prevailing national and international regulations and standards.*

*If you want to switch inductive loads (even relays or protection coils), you always have to dejam them! Otherwise there may occur interferences with the measuring signal. Also note the following items:*


- *If you use DC voltage, dejam the relay coil with a free-wheeling diode; refer to the following table and the following drawing "Interference suppression"!*
- *If dejamming is not possible, you have to assure that the relay contact is protected by a RC protection circuit! Also refer to the following table.*
- *If you use potential-free relay outputs, assure that a suitable shut-off device and a pre-fuse is installed in the feed line on site.*
- *When switching inductive loads, the manufacturer recommends a protective circuit to avoid unnecessarily high contact burn on the relay contact!*

*In delivery condition, the relay contacts are also suitable for low signal currents (from approx. 1 mA). Please note that the gold plating burns off during the switching operation when larger currents are used (from approx. 100 mA). Afterwards, the relays can no longer reliably switch small currents!*

##### AC voltage: required capacitors and resistances for dejamming

Current up to	Capacitor	Resistor
60 mA	10 nF / 260 V	390 Ω / 2 W
70 mA	47 nF / 260 V	22 Ω / 2 W
150 mA	100 nF / 260 V	47 Ω / 2 W
1.0 A	220 nF / 260 V	47 Ω / 2 W

## Interference suppression (A = AC, B = DC)




- ① Resistor,  $R = 47\ldots390 \Omega$ , see table before
- ② Capacitor,  $C = 10\ldots220 \text{ nF}$ , see table before (e.g. Siemens MKC B 81 921)
- ③ Relay coil
- ④ Free-wheeling diode
- ⑤ Relay coil

## Required cable properties

- Maximum wire cross section:  $1.5 \text{ mm}^2 / 0.06 \text{ square inch}$
- Minimum stripping length for wires:  $8 \text{ mm} / 0.31"$

Note the following procedure, remove the cover and connect the cables accordingly:


## Step 1: removing the cover



*The screw under the cover (5) is not to be used as a cable connection. Do not loosen or remove the cover or the screw!*

- Start to remove the internal cover of the relay outputs (1) by pressing it down (2).
- Pull the cover forward (3), then upward out of the clip and remove it (2) and (4).
- Remove the cover of the earth terminal by pulling it upward (5).
- ⇒ You see the 10-pin terminal block which is fitted with a connected bridge.

## Step 2: connecting the cables



- Connect the cables to the single relay terminals (①) as described in the previous drawing (②), note the required cable properties!
- If you want to release a cable from the relay terminals, first unlock the locking device (③) with a suitable tool and pull out the cable (④).

*If a switching voltage is applied to connection "C" (⑥ in the previous drawing), relay contacts R1, R2 and R3 are supplied in parallel with the help of the link plug (⑤). This allows the voltage switched from the relays to be passed on. You can remove the bridge if this supply is not needed.*


- After you have connected all cables, refasten the cover of the relay outputs.
- Close the converter housing and tighten all screws of the housing.


## 5.1 Order code

*The characters of the order code highlighted in light grey describe the standard.*

VGA K 4	Type / housing converter
1	OPTISENS MAC 100
	<b>Sensor input A</b>
1	Conductivity (in preparation)
2	Toroidal Conductivity (in preparation)
3	pH/Redox
4	Cl <sub>2</sub>
5	ClO <sub>2</sub> (in preparation)
6	O <sub>3</sub> (in preparation)
7	H <sub>2</sub> O <sub>2</sub> (in preparation)
A	O <sub>2</sub> (in preparation)
M	Digital (in preparation)
	<b>Sensor input B</b>
0	None
1	Conductivity (in preparation)
2	Toroidal Conductivity (in preparation)
3	pH/Redox
A	O <sub>2</sub> (in preparation)
M	Digital (in preparation)
	<b>Signal output</b>
3	3 x 0/4...20 mA
4	3 x 0/4...20 mA, HART (in preparation)
	<b>Approvals</b>
0	None
1	ATEX Zone II (in preparation)
	<b>Relais</b>
0	None
3	3 x free programmable, mechanical, not for ATEX
4	3 x electronical (N/O only)
VGA T 4	Continued on next page

<b>Operation language</b>	
1	English
2	German
3	French
4	Spanish
5	Chinese
<b>Power supply</b>	
1	100...230 VAC
2	24 VAC/DC (in preparation)
3	24 VAC/DC ATEX (in preparation)
4	24 VAC/DC CSY (in preparation)
5	100...230 VAC CSA (in preparation)
<b>Options</b>	
1	Incl. wall mounting
<b>Documentation</b>	
0	None
1	English
2	German (in preparation)
3	French (in preparation)
<b>Cable feedthrough</b>	
1	For 1 sensor, 4 x M20
2	For 2 sensors, with int. temperature compensation
3	For 2 sensors and separate temperature measurement
<b>Options</b>	
0	None
1	ASR Automatic Sensor Cleaning
<b>Carried over from previous page</b>	
Complete order code	









## KROHNE product overview

- Electromagnetic flowmeters
- Variable area flowmeters
- Ultrasonic flowmeters
- Mass flowmeters
- Vortex flowmeters
- Flow controllers
- Level meters
- Temperature meters
- Pressure meters
- Analysis products
- Measuring systems for the oil and gas industry
- Measuring systems for sea-going tankers

Head Office KROHNE Messtechnik GmbH  
Ludwig-Krohne-Str. 5  
D-47058 Duisburg (Germany)  
Tel.: +49 (0)203 301 0  
Fax: +49 (0)203 301 10389  
info@krohne.de

The current list of all KROHNE contacts and addresses can be found at:  
[www.krohne.com](http://www.krohne.com)